



⚠ Read the safety information overleaf

Method Statement

1. Cut a slot into the horizontal mortar joint using a wall chaser
2. Clean the slot with a vacuum and thoroughly flush with water
3. Using the Bond Flex gun kit, insert a 10 mm depth bead of Bond Flex into the back of the slot
4. Using the finger trowel, push the Bar Flex into the bead of Bond Flex, ensuring good even coverage
5. Insert a bead of Bond Flex over the exposed Bar Flex and iron into the slot using a finger trowel
6. Re-point or fill the joint and leave ready for any decoration
7. Repeat 1-6 for the other required stitches

Guidelines

- A. Depth of slot is between 25 mm and 35 mm
- B. Bar Flex to be installed a minimum of 500 mm each side of the crack
- C. Vertical spacing of crack stitches is 450 mm (6 brick courses)
- D. Where a crack is within 500 mm of the end of a wall (as in A above), continue Bar Flex for at least 100 mm around the corner and fix into the adjoining wall
- E. Where a crack is within 500 mm of an opening (as in B above), bend Bar Flex back and fix into the reveal

Materials



6 mm Bar Flex



Bond Flex



Water

Tooling



Angle Grinder



Vacuum



Bond Flex Gun Kit



Finger Trowel

Safety Equipment



Dust Mask



Eye Protection



Hand Protection



Ear Protection