



⚠ Read the safety information overleaf

Method Statement

1. Rake out or cut slots into horizontal mortar joints
2. Vacuum out the slots and thoroughly flush with water
3. Using the Bond Flex gun kit, insert a 10 mm depth bead of Bond Flex into back of the slot
4. Push the Bar Flex into the Bond Flex to obtain good coverage
5. Insert a further bead of Bond Flex over the exposed rod and iron into the slot using the finger trowel
6. Re-point or fill the rest of the slot and leave ready for decoration

Guidelines

- A. Depth of slot is between 25 and 45 mm
- B. Vertical spacing between Bar Flex is typically 450 mm (6 brick courses)
- C. Bar Flex to extend a minimum of 500 mm each side of the crack
- D. Continue Bar Flex at least 100 mm around the corner of the wall and bond as described in method statement
- E. Bar Flex is 6 mm diameter

Materials



6mm Bar Flex



Bond Flex



Water

Tooling



Angle Grinder



Vacuum



Bond Flex Gun Kit



Finger Trowel

Safety Equipment



Dust Mask



Eye Protection



Hand Protection



Ear Protection

Need help?

Our nationwide installation team is fully trained and insured to carry out this installation. Find your local branch now