



**⚠ Read the safety information overleaf**

## Method Statement

1. Rake out or cut slots into horizontal mortar joints
2. Vacuum out the slots and thoroughly flush with water
3. Using the Bond Flex gun kit, insert a 10 mm depth bead of Bond Flex into back of the slot
4. Push the Bar Flex into the Bond Flex to obtain good coverage
5. Insert a further bead of Bond Flex over the exposed Bar Flex and iron into the slot using the finger trowel
6. Repeat steps 4-5 with a second piece of Bar Flex
7. Re-point or fill the rest of the slot and leave ready for decoration

## Guidelines

- A. Depth of slot is between 55 and 70 mm
- B. For long lengths of Bar Flex, overlap runs by a minimum of 500 mm
- C. Top and bottom reinforcements should be positioned as far apart as practicable (maximum 12 courses or 900 mm)
- D. Bar Flex is 6 mm diameter

## Materials



6 mm Bar Flex



Bond Flex



Water

## Tooling



Angle Grinder



Vacuum



Bond Flex Gun Kit



Finger Trowel

## Safety Equipment



Dust Mask



Eye Protection



Hand Protection



Ear Protection